


PC412-D/PC406-D/PC412-DI/PC406-DI Block Diagram



*1 Can be configured only by recalling Speaker Preset data.
 *2 Available in future firmware release.
 *3 Accessible only from PC software.